

Cisco Router Configuration Basics

Router Components

□ RAM

- Holds operating system, data structures, packet buffers, ARP cache, and routing tables
- Router's **running-config is stored in RAM**

□ Flash memory

- **Holds the IOS**
- Is not erased when the router is reloaded

□ NVRAM

- Non-Volatile RAM - **stores router startup-config**
- Is not erased when router is reloaded

Router Components

□ Configuration Register

- controls how router boots;
- value can be seen with “`show version`” command;
- is normally `0x2102`, which tells the router to load the IOS from flash memory and the `startup-config` file from NVRAM
- `0x2142`, tells the router to ignore the NVRAM configuration when rebooting
- Leading “0x” means “hexadecimal”

Purpose of the Config Register

- Reasons why you would want to modify the config-register:
 - Force the router into ROM Monitor Mode
 - Select a boot source and default boot filename
 - Enable/Disable the Break function
 - Control broadcast addresses
 - Set console terminal baud rate
 - Load operating software from ROM

Configuration Overview

- Router configuration controls the operation of the router's:
 - Interface IP address and netmask
 - Routing information (static, dynamic or default)
 - Boot and startup information
 - Security (passwords and authentication)

Where is the Configuration?

- Router always has two configurations:
 - Running configuration
 - In RAM, determines how the router is currently operating
 - Is modified using the `configure` command
 - To see it: `show running-config`
 - Startup configuration
 - In NVRAM, determines how the router will operate after next reload
 - Is modified using the `copy` command
 - To see it: `show startup-config`

Where is the Configuration?

- ❑ Can also be stored in more permanent places:
 - External hosts, using TFTP, FTP, SCP, etc
 - In flash memory in the router
- ❑ Copy command is used to move it around

```
copy run start
```

```
copy run tftp
```

```
copy start tftp
```

```
copy tftp start
```

```
copy flash start
```

```
copy start flash
```

Router Access Modes

- ❑ User mode – limited access to router – no configuration rights
 - Router>
- ❑ Privileged EXEC mode – detailed access and full configuration of the router, debugging, testing, file manipulation (router prompt changes to an octothorp)
 - Router#
- ❑ ROM Monitor – useful for password recovery (amongst others)
- ❑ Setup Mode – entered when router has no **startup-config** file

External Configuration Sources

- Console
 - Direct PC serial access
- Auxiliary port
 - Modem access
- Virtual terminals
 - Telnet/SSH access
- TFTP Server
 - Copy configuration file into router RAM
- Network Management Software
 - e.g., CiscoWorks

Changing the Configuration

- ❑ Configuration statements can be entered interactively
 - changes are made (almost) immediately, to the running configuration
- ❑ Can use direct serial connection to console port, or
- ❑ Telnet/SSH to vty's ("virtual terminals"), or
- ❑ Modem connection to aux port, or
- ❑ Edited in a text file and uploaded to the router at a later time via tftp/ftp/scp
 - `copy tftp start` or `config net`

Logging into the Router

- ❑ Connect router to console port or telnet to router

```
router>
```

```
router>enable
```

```
password
```

```
router#
```

```
router#?
```

- ❑ Configuring the router

- Terminal (entering the commands directly)

```
router# configure terminal
```


```
router(config) #
```

Connecting your to your PC and Router

- ❑ Connect to your PC console port using below command
- ❑ Your PC will have a port number assigned by the instructor

- ❑ `telnet 155.12.64.2 PC-PORT-NUMBER`
- ❑ `telnet 155.12.64.2 ROUTER -PORT NUMBER`

Address Assignments



Configuring your Router (1)

- ❑ Load configuration parameters into RAM
 - Router#configure terminal

- ❑ Personalize router identification
 - Router#(config)hostname RouterA

- ❑ Assign console & vty passwords
 - RouterA#(config)line console 0
 - RouterA#(config-line)password *si2010*

 - RouterA#(config)line vty 0 4
 - RouterA#(config-line)password *si2010*

Configuring your Router (2)

- ❑ Set the enable (secret) password:
 - `router(config)# enable secret nog`
 - ❑ This MD5 encrypts the password
 - The old method was to use the `enable password` command. But this is not secure (weak encryption) and is **ABSOLUTELY NOT RECOMMENDED. DO NOT USE!**

- ❑ Ensure that all passwords stored on router are (weakly) encrypted rather than clear text:
 - `router(config)# service password-encryption`

Configuring your Router (3)

- Configure interfaces
 - RouterA# (config) interface fastethernet 0/0
 - RouterA# (config-if) ip address n.n.n.n m.m.m.m
 - RouterA# (config-if) no shutdown

- Configure routing/routed protocols
 - RouterA# (config) router bgp 100
 - RouterA# (config-router)

- Save configuration parameters to NVRAM
 - RouterA# copy running-config startup-config
 - (or write memory)

Configuring your Router (4)

□ IP Specific Configuration

- `no ip source-route` → disable source routing
- `ip domain-name domain-name`
- `ip nameserver n.n.n.n` → set name server

□ Static Route Creation

`ip route n.n.n.n m.m.m.m g.g.g.g`

n.n.n.n = network block

m.m.m.m = network mask denoting block size

g.g.g.g = next hop gateway destination packets are sent to

Router Prompts – How to tell where you are on the router

- ❑ You can tell in which area of the router's configuration you are by looking at the router prompts - some examples:

`Router>` → USER prompt mode

`Router#` → PRIVILEGED EXEC prompt mode

`Router(config)` → terminal configuration prompt

`Router(config-if)` → interface configuration prompt

`Router(config-subif)` → sub-interface configuration prompt

`rommon 1>` → ROM Monitor mode

The NO Command

- Used to reverse or disable commands e.g

```
ip domain-lookup  
no ip domain-lookup
```

```
router ospf 1  
no router ospf 1
```

```
ip address 1.1.1.1 255.255.255.0  
no ip address
```

Interface Configuration

- ❑ Interfaces are named by slot/type; e.g.:
 - ethernet0, ethernet5/1, serial0/0/0, serial2
- ❑ And can be abbreviated:
 - ethernet0 or eth0 or e0
 - Serial0/0 or ser0/0 or s0/0
- ❑ Interfaces are shutdown by default
 - `router(config-if)#no shutdown` → wake up interface
- ❑ Description
 - `router(config-if)#description Link to Admin Building router`

Global Configuration Commands

- ❑ Cisco **global** config should always include:
 - `ip classless`
 - `ip subnet-zero`
 - (These are default as from IOS 12.2 release)
- ❑ Cisco **interface** config should usually include:
 - `no shutdown`
 - `no ip proxy-arp`
 - `no ip redirects`
 - `no ip directed-broadcast`
- ❑ Industry recommendations are at <http://www.cymru.com/Documents>

Looking at the Configuration

- Use “`show running-configuration`” to see the current configuration
- Use “`show startup-configuration`” to see the configuration in NVRAM, that will be loaded the next time the router is rebooted or reloaded
 - (or `show conf`)

Storing the Configuration on a Remote System

- ▣ Requires: 'tftpd' on a unix host; destination file must exist before the file is written and must be world writable...

```
rtra#copy run tftp
Remote host []? n.n.n.n
Name of configuration file to write [rtra-config]?
Write file rtra-config on Host n.n.n.n? [confirm]
Building configuration...
```

```
Writing rtra-config !! [OK]
router#
```

Restoring the Configuration from a Remote System

- Use 'tftp' to pull file from UNIX host, copying to running-config (added to existing running configuration) or startup-config (stored in configuration NVRAM and used on next reboot)

```
rtra#copy tftp start
Address of remote host [255.255.255.255]? n.n.n.n
Name of configuration file [rtra-config]?
Configure using rtra-config from n.n.n.n? [confirm]
Loading rtra-config from n.n.n.n (via
  Ethernet0/0): !
[OK - 1005/128975 bytes]
rtra# reload
```


Getting Command Help

- IOS has a command help facility;
 - use “?” to get a list of possible configuration options
- “?” after the prompt lists all possible commands:
`router#?`
- “<command> ?” lists all possible subcommands
`router#show ?`
`router#show ip ?`
- “<partial command>?” lists all possible command completions:
`router#con?`
`configure connect`

Getting Lazy Command Help

- TAB character will complete a partial word

```
hostel-rtr(config)#int<TAB>
```

```
hostel-rtr(config)#interface et<TAB>
```

```
hostel-rtr(config)#interface ethernet 0
```

```
hostel-rtr(config-if)#ip add<TAB>
```

```
hostel-rtr(config-if)#ip address n.n.n.n m.m.m.m
```

- Not really necessary to complete command keywords; partial commands can be used:

```
router#conf t
```

```
router(config)#int e0/0
```

```
router(config-if)#ip addr n.n.n.n
```

Editing

□ Command history

- IOS maintains a list of previously typed commands
- up-arrow or '^p' recalls previous command
- down-arrow or '^n' recalls next command

□ Line editing

- left-arrow, right-arrow moves cursor inside command
- '^d' or backspace will delete character in front of cursor
- Ctrl-a takes you to start of line
- Ctrl-e takes you to end of line

Connecting your FreeBSD machine to the Router's Console port

- ❑ Look at your running configuration
- ❑ Configure an IP address for fastethernet0/0 depending on your table
 - use n.n.n.n for table A etc
- ❑ Look at your running configuration and your startup configuration
- ❑ Check what difference there is, if any

Deleting your Router's Configuration

- To delete your router's configuration

```
Router#erase startup-config
```

OR

```
Router#write erase
```

```
Router#reload
```

- Router will start up again, but in setup mode, since startup-config file does not exist

Password Recovery



Working around a forgotten or
lost password

Disaster Recovery – ROM Monitor

- ROM Monitor is very helpful in recovering from emergency failures such as:
 - Password recovery
 - Upload new IOS into router with NO IOS installed
 - Selecting a boot source and default boot filename
 - Set console terminal baud rate to upload new IOS quicker
 - Load operating software from ROM
 - Enable booting from a TFTP server

Getting to the ROM Monitor

- ❑ Windows using HyperTerminal for the console session
 - Ctrl-Break

- ❑ FreeBSD/UNIX using Tip for the console session
 - <Enter>, then ~# OR
 - Ctrl-], then Break or Ctrl-C

- ❑ Linux using Minicom for the console session
 - Ctrl-A F

- ❑ MacOS using Zterm for the console session
 - Apple B

Disaster Recovery:

How to Recover a Lost Password

- ❑ Connect your PC's serial port to the router's console port
- ❑ Configure your PC's serial port:
 - 9600 baud rate
 - No parity
 - 8 data bits
 - 1 stop bit
 - No flow control

Disaster Recovery:

How to Recover a Lost Password

- ❑ Your configuration register should be 0x2102; use “**show version**” command to check
- ❑ Reboot the router and apply the Break-sequence within 60 seconds of powering the router, to put it into ROMMON mode

```
Rommon 1>confreg 0x2142
```

```
Rommon 2>reset
```

- Router reboots, bypassing startup-config file

Disaster Recovery: How to Recover a Lost Password

Type Ctrl-C to exit Setup mode

```
Router>enable
```

```
Router#copy start run (only!!!)
```

```
Router#show running
```

```
Router#conf t
```

```
Router(config)enable secret forgotten
```

```
Router(config)int e0/0...
```

```
Router(config-if)no shut
```

```
Router(config)config-register 0x2102
```

```
Router(config)Ctrl-Z or end
```

```
Router#copy run start
```

```
Router#reload
```

Basic IPv6 Configuration

IPv6 Configuration

- ❑ IPv6 is not enabled by default in IOS
- ❑ Enabling IPv6:
Router(config)# ipv6 unicast-routing
- ❑ Disable Source Routing
Router(config)# no ipv6 source route
- ❑ Activating IPv6 CEF
Router(config)# ipv6 cef

IPv6 Configuration - Interfaces

- ❑ Configuring a global or unique local IPv6 address:
 - Router(config-if)# ipv6 address X:X..X:X/prefix

- ❑ Configuring an EUI-64 based IPv6 address (not such a good idea on a router):
 - Router(config-if)# ipv6 address X:X::/prefix
eui-64

IPv6 Configuration

- ❑ Note that by configuring any IPv6 address on an interface, you will see a global or unique-local IPv6 address and a link-local IPv6 address on the interface
 - Link-local IPv6 address format is *FE80::interface-id*

- ❑ The local-link IPv6 address is constructed automatically by concatenating FE80 with Interface ID as soon as IPv6 is enabled on the interface:
 - Router(config-if)# `ipv6 enable`

IOS IPv6 Interface Status – Link Local

```
br01#sh ipv6 interface fast 0/1.220
FastEthernet0/1.220 is up, line protocol is up
  IPv6 is enabled, link-local address is FE80::225:45FF:FE6A:5B39
  No global unicast address is configured
  Joined group address(es):
    FF02::1
    FF02::2
    FF02::1:FF6A:5B39
  MTU is 1500 bytes
  ICMP error messages limited to one every 100 milliseconds
  ICMP redirects are enabled
```


IOS IPv6 Interface Status

```
br01#sh ipv6 interface fast 0/1.223
```

```
FastEthernet0/1.223 is up, line protocol is up
```

```
IPv6 is enabled, link-local address is FE80::225:45FF:FE6A:5B39
```

```
Description: backbone
```

```
Global unicast address(es):
```

```
2001:4348:0:223:196:200:223:254, subnet is 2001:4348:0:223::/64
```

```
Joined group address(es):
```

```
FF02::1
```

```
FF02::2
```

```
FF02::1:FF23:254
```

```
FF02::1:FF6A:5B39
```

```
MTU is 1500 bytes
```

```
ICMP error messages limited to one every 100 milliseconds
```

```
ICMP redirects are enabled
```

IPv6 Configuration – Miscellaneous

- ❑ Disable IPv6 redirects on interfaces

```
interface fastethernet 0/0  
  no ipv6 redirects
```

- ❑ Nameserver, syslog etc can be IPv6 accessible

```
ip nameserver 2001:db8:2:1::2  
ip nameserver 10.1.40.40
```

Static Routing – IOS

□ Syntax is:

```
ipv6 route ipv6-prefix/prefix-length {ipv6-  
address | interface-type interface-number}  
[admin-distance]
```

□ Static Route

```
ipv6 route 2001:db8::/64 2001:db8:0:CC00::1
```

- Routes packets for network 2001:db8::/64 to a networking device at 2001:db8:0:CC00::1

Cisco Router Configuration Basics

Questions?